


Please follow these steps to finish upgrading your XING devices:

1. Unplug the XING USB device.
2. Press and hold the **setting mode enter button** (pointed by red arrow in following picture), then plug the device to the computer. Release the button after 2 or 3 seconds.




3. If the device is detected successfully, you can find an item called **USB HiRes Audio F-20 Configuration** under **libusb-win32 devices** or **Generic Serial Bus Device** on Windows Device Manager. Now the device is ready for being upgraded.



4. Double click **\_Start\_Upgrade\_Firmware** program file from this package to start the upgrade process.



5. Wait about 10 or 15 seconds to finish the process. At the end, press any key to close the upgrade window.



```
C:\WINDOWS\system32\cmd.exe
Start updating firmware master_cf7324c.fmw with par-v2.16.2.cfg and u20-uac2-v2.17.1.fmc
XING Digital Audio Technical Team
Firmware Programmer v1.3.0
Flashing progress.....
Firmware upgrade successfully.
Update firmware success
请按任意键继续. . .
```

6. Unplug the XING device to exit configuration mode. It is ready for use now. Enjoy the Music.